
PROCESS
RAMAC
TAPE
EXT I/O
READER
PUNCH
OVERLAP
PRINTER
STORAGE
B
A
LOGIC
OP
STORAGE ADDRESS
INSTRUCTION LENGTH
A AUX REG
B AUX REG
I ADD REG
A ADD REG
B ADD REG
O ADD REG
MANUAL ADDRESS
RUN
ALTER
I/EX
CHARACTER DISPLAY
STORAGE PRINT OUT
SINGLE CYCLE PROCESS
SINGLE CYCLE NON-PROCESS
ADDRESS STOP
STORAGE SCAN
START RESET
I/O CHECK STOP
A
B
C
D
E
F
G
N
EMERGENCY OFF
CHECK RESET
POWER ON
POWER OFF
TAPE LOAD
BACK SPACE